

LDLM AD 2.1 NAZIV I OZNAKA MJESTA AERODROMA
LDLM AD 2.1 AERODROME LOCATION INDICATOR AND NAME

LDLM - AERODROM NA VODI MALI LOŠINJ
LDLM - WATER AERODROME MALI LOŠINJ

LDLM AD 2.2 ZEMLJOPISNI I ADMINISTRATIVNI PODACI O
AERODROMU
LDLM AD 2.2 AERODROME GEOGRAPHICAL AND
ADMINISTRATIVE DATA

1	<i>ARP koordinate i položaj na AD</i> <i>ARP coordinates and site at AD</i>	443315.34 N 0142625.18 E
2	<i>Smjer i udaljenost od (grada)</i> <i>Direction and distance from (city)</i>	1.9 NM NW od/from Mali Lošinj
3	<i>Nadmorska visina/Odnosna temperatura</i> <i>AD Elevation/Reference temperature</i>	0 FT / 25°C (AUG)
4	<i>Geoidna undulacija na/Geoid undulation at</i> <i>AD ELEV PSN</i>	42.81 M (141 FT)
5	<i>MAG VAR/Godišnja promjena</i> <i>MAG VAR/Annual change</i>	3°E (2012) / 0.1° u porastu / increasing
6	<i>Operator AD, adresa, telefon, telefax, AFS,</i> <i>E-mail, Web site</i> <i>AD Operator; address, telephone, telefax,</i> <i>AFS, E-mail, Web site</i>	European Coastal Airlines Put Divulja 7 21 217 Kaštel Štafilić, Croatia Phone: (+385 21) 444888 Mobile: (+385 92) 2714555 E-mail: losinj@ec-air.eu Web site: www.ec-air.eu
7	<i>Dozvoljene vrste prometa (IFR/VFR)</i> <i>Types of traffic permitted (IFR/VFR)</i>	VFR
8	<i>Primjedbe</i> <i>Remarks</i>	NIL

LDLM AD 2.3 RADNA VREMENA
LDLM AD 2.3 OPERATIONAL HOURS

1	<i>Operator AD / AD Operator</i>	O/R - 2 HR PPR
2	<i>Carinska kontrola i kontrola putovnica / Customs and immigration</i>	O/R
3	<i>Zdravstvo i sanitetske mjere / Health and sanitation</i>	NIL
4	<i>AIS ured za informiranje / AIS Briefing Office</i>	NIL
5	<i>ATS prijavni ured (ARO) / ATS Reporting Office (ARO)</i>	H24 - Central ARO Split TEL: +385 21 205444 FAX: +385 21 895227
6	<i>MET ured za informiranje / MET Briefing Office</i>	NIL Vidi/See AIP LDLO AD 2.11
7	<i>ATS</i>	NIL
8	<i>Opskrba gorivom / Fuelling</i>	NIL
9	<i>Prihvat i otprema / Handling</i>	NIL
10	<i>Osiguranje / Security</i>	NIL
11	<i>Odleđivanje / De-icing</i>	NIL
12	<i>Primjedbe / Remarks</i>	NIL

LDLM AD 2.4 SLUŽBE I OPREMA ZA PRIHVAT I OTPREMU
LDLM AD 2.4 HANDLING SERVICES AND FACILITIES

NIL

LDLM AD 2.5 USLUGE NA RASPOLAGANJU PUTNICIMA
LDLM AD 2.5 PASSENGER FACILITIES

1	<i>Hoteli / Hotels</i>	U gradu / In the city
2	<i>Restorani / Restaurants</i>	U gradu / In the city
3	<i>Prijevoz / Transportation</i>	Autobus / Bus
4	<i>Liječničke usluge / Medical facilities</i>	U gradu / In the city
5	<i>Banka i pošta / Bank and Post Office</i>	U gradu / In the city
6	<i>Turističke informacije / Tourist Office</i>	U gradu / In the city
7	<i>Primjedbe / Remarks</i>	Nil

LDLM AD 2.6 SLUŽBE SPAŠAVANJA I VATROGASNE SLUŽBE
LDLM AD 2.6 RESCUE AND FIRE FIGHTING SERVICES

1	<i>AD vatrogasna kategorija / AD category for fire fighting</i>	CAT 3
2	<i>Oprema za spašavanje / Rescue equipment</i>	1 brod / boat
3	<i>Mogućnosti uklanjanja onesposobljenog zrakoplova / Capability for removal of disabled aircraft</i>	Brod za vuču. Kontaktirati operatora AD-a na broj / Towing boat. Contact AD operator on mobile phone: (+385 92) 2714555
4	<i>Primjedbe / Remarks</i>	Nil

LDLM AD 2.7 MOGUĆNOST SEZONSKOG ČIŠĆENJA
LDLM AD 2.7 SEASONAL AVAILABILITY - CLEARING

Nil

**LDLM AD 2.8 PODACI O STAJANKAMA, STAZAMA ZA VOŽNJU I
MJESTIMA PROVJERE**

**LDLM AD 2.8 APRONS, TAXIWAYS AND CHECK LOCATIONS
DATA**

1	<i>Površina stajanke i nosivost / Apron surface and strength</i>	Površina/Surface: Voda/Water Nosivost/Strength: Nil
2	<i>Oznaka, širina, vrsta površine i nosivost staze za vožnju / Taxiway designation, width, surface and strength</i>	Širina/Width: Nil Površina/Surface: Voda/Water Nosivost/ Strength: Nil
3	<i>Položaj ACL-a i nadmorska visina / ACL location and elevation</i>	Nil
4	<i>VOR kontrolne točke /VOR checkpoints INS kontrolne točke / INS checkpoints</i>	Nil
5	<i>Primjedbe / Remarks</i>	Nil

**LDLM AD 2.9 SUSTAV VOĐENJA I KONTROLE KRETANJA I
OZNAKE**

**LDLM AD 2.9 SURFACE MOVEMENT GUIDANCE AND
CONTROL SYSTEM AND MARKINGS**

Nil

LDLM AD 2.10 AERODROMSKE PREPREKE
LDLM AD 2.10 AERODROME OBSTACLES

<i>U području 2/In Area 2</i>					
<i>OBST ID/Oznaka OBST ID/Designation</i>	<i>Tip OBST/ OBST type</i>	<i>Pozicija OBST/ OBST position</i>	<i>ELEV/HGT</i>	<i>Oznake/ Tip, boja Markings/ Type, colour</i>	<i>Primjedbe /Remarks</i>
1	Dalekovod /Powerline	443421.20N 0142527.42E	256 FT(78M) / NIL	NIL	14/APCH 32/TKOF
2	Kopno/ Terrain	443434.03N 0142515.92E	360 FT(109.5M) / NIL	NIL	14/APCH 32/TKOF
3	Dalekovod /Powerline	443432.41N 0142514.07E	338 FT(103M) / NIL	NIL	14/APCH 32/TKOF
4	Kopno/ Terrain	443440.30N 0142511.00E	348 FT(106M) / NIL	NIL	14/APCH 32/TKOF
5	Dalekovod /Powerline	443438.51N 0142507.96E	325 FT(99M) / NIL	NIL	14/APCH 32/TKOF

<i>U području 3/In Area 3</i>					
<i>OBST ID/Oznaka OBST ID/Designation</i>	<i>Tip OBST/ OBST type</i>	<i>Pozicija OBST/ OBST position</i>	<i>ELEV/HGT</i>	<i>Oznake/ Tip, boja Markings/ Type, colour</i>	<i>Primjedbe/ Remarks</i>
NIL	NIL	NIL	NIL	NIL	NIL

LDLM AD 2.11 RASPOLOŽIVE METEOROLOŠKE INFORMACIJE
LDLM AD 2.11 METEOROLOGICAL INFORMATION PROVIDED

1	<i>Pridružen MET ured / Associated MET Office</i>	NIL
2	<i>Radno vrijeme MET ured izvan radnog vremena / Hours of service MET Office outside hours</i>	NIL
3	<i>Ured nadležan za pripremu TAF-a Razdoblja valjanosti / Office responsible for TAF preparation Periods of validity</i>	NIL
4	<i>Vrsta prognoze za slijetanje Interval izdavanja / Type of landing forecast Interval of issuance</i>	NIL
5	<i>Mogućnost informiranja/konzultacije / Briefing/consultation provided</i>	https://met.crocontrol.hr Osobne konzultacije telefonom, vidi/ Personal briefing by telephone, see AIP LDLO AD 2.11
6	<i>Dokumentacija u svezi leta Korišteni jezik(ci) / Flight documentation Language(s) used</i>	NIL
7	<i>Karte i ostali podaci raspoloživi za informiranje ili konzultacije / Charts and other information available for briefing or consultation</i>	NIL
8	<i>Dodatni raspoloživi uređaji za pružanje informacija / Supplementary equipment available for providing information</i>	NIL
9	<i>ATS jedinice opskrbljene informacijama / ATS unit provided with information</i>	NIL
10	<i>Dodatne informacije (ograničenja u pružanju usluge, itd.) / Additional information (limitation of service, etc.)</i>	NIL

**LDLM AD 2.12 FIZIČKE KARAKTERISTIKE POVRŠINE ZA
SLIJETANJE I UZLIJETANJE -PLOVNI KANAL
LDLM AD 2.12 WATERWAY PHYSICAL CHARACTERISTICS**

<i>Oznake RWY NR</i>	<i>TRUE BRG</i>	<i>Dimenzije RWY-a (M)</i>	<i>Nosivost (PCN) i površina RWY- a i SWY-a</i>	<i>Koordinate THR Koordinate kraja RWY-a Geoidna undulacija THR-a</i>	<i>Nadmorska visina THR-a, najviša nadmorska visina TDZ-a kod RWY-a za precizan prilaz</i>
<i>Designations RWY NR</i>	<i>TRUE BRG</i>	<i>Dimensions of RWY (M)</i>	<i>Strength (PCN) and surface of RWY and SWY</i>	<i>THR coordinates RWY end coordinates THR geoid undulation</i>	<i>THR elevation and highest elevation of TDZ of precision APP RWY</i>
1	2	3	4	5	6
14	142.89°	500x150	Nil Voda/Water	443354.69 N 0142546.87 E Nil Nil	0 FT
32	322.89°	500x150	Nil Voda/Water	443341.78 N 0142600.53 E Nil Nil	0 FT
13	133.81°	500x150	Nil Voda/Water	443248.06 N 0142648.47 E Nil Nil	0 FT
31	313.81°	500x150	Nil Voda/Water	443236.85 N 0142704.81 E Nil Nil	0 FT
<i>Nagib RWY- SWY-a</i>	<i>Dimenzije SWY-a (M)</i>	<i>Dimenzije CWY-a (M)</i>	<i>Waterway strip dimenzije/ dimensions (M)</i>	<i>OFZ</i>	<i>Primjedbe</i>
<i>Slope of RWY-SWY</i>	<i>SWY dimensions (M)</i>	<i>CWY dimensions (M)</i>		<i>OFZ</i>	<i>Remarks</i>
7	8	9	10	11	12
Nil	Nil	Nil	Nil	Nil	Nil

LDLM AD 2.13 OBJAVLJENE UDALJENOSTI
LDLM AD 2.13 DECLARED DISTANCES

<i>Oznaka RWY-a</i>	<i>TORA</i>	<i>TODA</i>	<i>ASDA</i>	<i>LDA</i>	<i>Primjedbe</i>
<i>RWY</i>	<i>(M)</i>	<i>(M)</i>	<i>(M)</i>	<i>(M)</i>	
<i>Designator</i>	<i>TORA</i>	<i>TODA</i>	<i>ASDA</i>	<i>LDA</i>	<i>Remarks</i>
<i>(M)</i>	<i>(M)</i>	<i>(M)</i>	<i>(M)</i>	<i>(M)</i>	
<i>1</i>	<i>2</i>	<i>3</i>	<i>4</i>	<i>5</i>	<i>6</i>
14	500	500	500	500	Voda, bez prepreka/ Water, no obstacles
32	500	500	500	500	Voda, bez prepreka/ Water, no obstacles
13	500	500	500	500	Voda, bez prepreka/ Water, no obstacles
31	500	500	500	500	Voda, bez prepreka/ Water, no obstacles

LDLM AD 2.14 PRILAZNA SVJETLA I OSVJETLJENJE UZLETNO-SLETNE STAZE

LDLM AD 2.14 APPROACH AND RUNWAY LIGHTING

Nil

LDLM AD 2.15 OSTALA OSVJETLJENJA, SEKUNDARNI IZVOR ELEKTRIČNE ENERGIJE

LDLM AD 2.15 OTHER LIGHTING, SECONDARY POWER SUPPLY

Nil

LDLM AD 2.16 PROSTOR ZA SLIJETANJE HELIKOPTERA
LDLM AD 2.16 HELICOPTER LANDING AREA

Nil

LDLM AD 2.17 ZRAČNI PROSTOR U NADLEŽNOSTI ATS-A
LDLM AD 2.17 ATS AIRSPACE

1	<i>Oznake i bočne granice / Designation and lateral limits</i>	Nil
2	<i>Vertikalne granice / Vertical limits</i>	Nil
3	<i>Klasifikacija zračnog prostora / Airspace classification</i>	D
4	<i>Pozivni znak ATS jedinice Jezik(ci) / ATS unit call sign Language(s)</i>	Lošinj Toranj / Lošinj Tower EN/HR
5	<i>Prijelazna apsolutna visina / Transition altitude</i>	10 000 FT MSL
6	<i>Primjedbe / Remarks</i>	Nil

LDLM AD 2.18 KOMUNIKACIJSKE SLUŽBE ATS-A
LDLM AD 2.18 ATS COMMUNICATION FACILITIES

Nil

**LDLM AD 2.19 RADIONAVIGACIJSKI UREĐAJI I UREĐAJI ZA
SLIJETANJE**
LDLM AD 2.19 RADIONAVIGATION AND LANDING AIDS

Nil

LDLM AD 2.20 LOKALNI AERODROMSKI PROPISI
LDLM AD 2.20 LOCAL AERODROME REGULATIONS

Prije uzlijetanja ili slijetanja pilot mora kontaktirati VTS (Hrvatski sustav nadzora i upravljanja pomorskim prometom) na VHF kanalu 14 i Lučku kapetaniju Lošinj na VHF kanalu 09 ili 16.

Osobe ili plovila koja ulaze na operativne površine moraju se pridržavati upute odgovorne osobe. Ulaz na ponton za privez hidroaviona na Aerodromu na vodi Mali Lošinj je pod nadzorom djelatnika operatora aerodroma na vodi.

Pristajanje i parkiranje zrakoplova na pristanišni ponton obavlja pilot.

Pomoćno osoblje operatera aerodroma, upoznato sa operativnim i sigurnosnim procedurama vezanim uz prihvat i privez hidroaviona, pomaže pilotu pri pristajanju i privezu na platformu.

Pristanišna platforma koristi se isključivo za privez hidroaviona i pomoćnih operativnih plovila Aerodroma na vodi Mali Lošinj.

Prior to landing or take-off pilot shall contact VTS (Vessel Traffic Service) on VHF channel 14 and Harbour master Lošinj on marine VHF 09 or 16 channel.

Persons and vessels entering LDLM operational surfaces shall follow Water aerodrome Mali Lošinj personnel instructions. Entrance to the dock is under supervision of aerodrome personnel.

Docking and parking procedure is at pilot discretion. Aerodrome personnel, trained in operational and safety procedures regarding docking and mooring, will help with tie down during docking of seaplane.

Dock is used for seaplanes and LDLM operational vessels mooring only.

LDLM AD 2.21 POSTUPCI ZA SMANJENJE BUKE **LDLM AD 2.21 NOISE ABATEMENT PROCEDURES**

Nil

LDLM AD 2.22 POSTUPCI TIJEKOM LETA **LDLM AD 2.22 FLIGHT PROCEDURES**

Zrakoplovi koji odlaze sa Aerodroma na vodi Mali Lošinj primarno uspostavljaju radio-komunikaciju prije polijetanja na frekvenciji Lošinj TWR, vidi LDLO AD 2.18..

Ukoliko pilot nije u mogućnosti uspostaviti kontakt sa Lošinj TWR potrebno je kontaktirati Pula Radar, vidi ENR 2.1..

Tijekom otvorenosti ATS LDLO pilot postupa sukladno izdanim odobrenjima nadležne KZP TWR Lošinj.

Izvan radnog vremena ATS LDLO pilot zrakoplova u odlasku/dolasku postupa sukladno objavljenim podacima u VFR priručniku, pod LDLO AD 2.22.1 “VFR postupci tijekom leta”.

NAPOMENA: Izvan Lošinj ATS OPR HR aktivna ATZ Lošinj istih lateralnih granica kao CTR Lošinj sa vertikalnim granicama do 1000 FT AGL, klasifikacija prostora G.

DOLET / ODLET

Iz smjera W-SW dolet/odlet vršiti iz/u pravcu S3 na visini 1000 FT AGL.

Iz smjera NE dolet/odlet vršiti iz/u pravcu T1 na visini 1000 FT AGL.

Iz smjera SE dolet/odlet vršiti iz/u pravcu H2 na visini 1000 FT AGL.

OPREZ

Zrakoplovi na instrumentalnom prilazu NDB-a RWY 02/20, ACFT CAT A&B.
Visoki teren otok Lošinj u prilazu za RWY 14.

ŠKOLSKI KRUG

Školski krug je desni za stazu 14, a lijevi za stazu 32 na visini od 500 FT AGL.

Školski krug je desni za stazu 13, a lijevi za stazu 31 na visini od 500 FT AGL.

Aircraft departing from Water aerodrome Mali Lošinj shall before take-off contact Lošinj TWR, see LDLO AD 2.18..

If contact on the Lošinj TWR frequency 120.300 MHz cannot be established, pilot shall contact Pula Radar, see ENR 2.1..

During operating hours of ATS unit TWR Lošinj, pilot shall follow TWR Lošinj ATC clearance to/from water aerodrome Mali Lošinj.

Outside ATS LDLO OPR HR pilots are required to follow VFR Manual, LDLO AD 2.22.1 “VFR flight procedures”.

NOTE: Outside Lošinj ATS OPR HR, ATZ Lošinj activated within the same lateral limits as CTR Lošinj, with vertical limit up to 1000 FT AGL, airspace classification G.

ARRIVAL / DEPARTURE

W and SW arrival/ departure shall be made at altitude 1000 FT AGL to/from VFR reporting point S3.

NE arrival/departure shall be made at altitude 1000 FT AGL to/from VFR reporting point T1.

SE arrival/departure shall be made at altitude 1000 FT AGL to/from VFR reporting point H2.

CAUTION:

Aircraft on instrument approach NDB-a RWY 02/20, ACFT CAT A&B.
High terrain of Lošinj Island in approach area RWY 14.

TRAFFIC CIRCUIT

Traffic circuit is right-hand for RWY 14, and left-hand for RWY 32 at altitude 500 FT AGL.

Traffic circuit is right-hand for RWY 13, and left-hand for RWY 31 at altitude 500 FT AGL.

LDLM AD 2.23 DODATNE INFORMACIJE LDLM AD 2.23 ADDITIONAL INFORMATION

Nil

LDLM AD 2.24 POPRATNE KARTE AERODROMA LDLM AD 2.24 CHARTS RELATED TO AN AERODROME

<i>Ime / Name</i>	<i>Stranica / Page</i>
Aerodrome Chart	LDLM AD 2-ADC
Visual Approach Chart	LDLM AD 2-VAC