

LDSL AD 2.1 NAZIV I OZNAKA MJESTA AERODROMA
LDSL AD 2.1 AERODROME LOCATION INDICATOR AND NAME

LDSL - AERODROM NA VODI KORČULA/Vela Luka
LDSL - KORČULA/Vela Luka WATER AERODROME

LDSL AD 2.2 ZEMLJOPISN I ADMINISTRATIVNI PODACI O
AERODROMU
LDSL AD 2.2 AERODROME GEOGRAPHICAL AND
ADMINISTRATIVE DATA

1	<i>ARP koordinate i položaj na AD</i> <i>ARP coordinates and site at AD</i>	425746.83N 0164131.83E
2	<i>Smjer i udaljenost od (grada)</i> <i>Direction and distance from (city)</i>	1.1 NM NW od/from Vela Luka
3	<i>Nadmorska visina/Odnosna temperatura</i> <i>AD Elevation/Reference temperature</i>	0 FT / 27°C (AUG)
4	<i>Geoidna undulacija na/Geoid undulation at</i> <i>AD ELEV PSN</i>	42.98M (141 FT)
5	<i>MAG VAR/Godišnja promjena</i> <i>MAG VAR/Annual change</i>	3°E (2012) / 0.1° increasing
6	<i>Operator AD, adresa, telefon, telefax, AFS,</i> <i>E-mail, Web site</i> <i>AD Operator, address, telephone, telefax,</i> <i>AFS, E-mail, Web site</i>	European Coastal Airlines Put Divulja 7 21 217 Kaštel Štafilić, Croatia Telephone: (+385 21) 444888 Mobile: (+385 91) 3220082 E-mail: velaluka@ec-air.eu Web site: www.ec-air.eu
7	<i>Dozvoljene vrste prometa (IFR/VFR)</i> <i>Types of traffic permitted (IFR/VFR)</i>	VFR
8	<i>Primjedbe</i> <i>Remarks</i>	Nil

LDSL AD 2.3 RADNA VREMENA
LDSL AD 2.3 OPERATIONAL HOURS

1	<i>Operator AD / AD Operator</i>	O/R - 2 HR PPR
2	<i>Carinska kontrola i kontrola putovnica / Customs and immigration</i>	O/R
3	<i>Zdravstvo i sanitetske mjere / Health and sanitation</i>	Nil
4	<i>AIS ured za informiranje / AIS Briefing Office</i>	Nil
5	<i>ATS prijavni ured (ARO) / ATS Reporting Office (ARO)</i>	H24 - Central ARO Split TEL: +385 21 205444 FAX: +385 21 895227
6	<i>MET ured za informiranje / MET Briefing Office</i>	Nil Vidi primjedbe/See remarks
7	<i>ATS</i>	Nil
8	<i>Opskrba gorivom / Fuelling</i>	Nil
9	<i>Prihvat i otprema / Handling</i>	Nil
10	<i>Osiguranje / Security</i>	Nil
11	<i>Odleđivanje / De-icing</i>	Nil
12	<i>Primjedbe / Remarks</i>	MET informiranje moguće iz MET ureda Split, vidi/MET briefing AVBL from MET Office Split, see AIP LDSP AD 2.11

LDSL AD 2.4 SLUŽBE I OPREMA ZA PRIHVAT I OTPREMU
LDSL AD 2.4 HANDLING SERVICES AND FACILITIES

Nil

LDSL AD 2.5 USLUGE NA RASPOLAGANJU PUTNICIMA
LDSL AD 2.5 PASSENGER FACILITIES

1	<i>Hoteli / Hotels</i>	U gradu/In the city
2	<i>Restorani / Restaurants</i>	U gradu/In the city
3	<i>Prijevoz / Transportation</i>	Autobus/Bus
4	<i>Liječničke usluge / Medical facilities</i>	U gradu/ In the city
5	<i>Banka i pošta / Bank and Post Office</i>	U gradu/In the city
6	<i>Turističke informacije / Tourist Office</i>	U gradu/In the city
7	<i>Primjedbe / Remarks</i>	Nil

LDSL AD 2.6 SLUŽBE SPAŠAVANJA I VATROGASNE SLUŽBE
LDSL AD 2.6 RESCUE AND FIRE FIGHTING SERVICES

1	<i>AD vatrogasna kategorija / AD category for fire fighting</i>	CAT 3
2	<i>Oprema za spašavanje / Rescue equipment</i>	1 brod/boat
3	<i>Mogućnosti uklanjanja onesposobljenog zrakoplova / Capability for removal of disabled aircraft</i>	Brod za vuču. Kontaktirati operatora AD-a na broj: / Towing boat. Contact AD operator on mobile: (+385 91) 3220082
4	<i>Primjedbe / Remarks</i>	Nil

LDSL AD 2.7 MOGUĆNOST SEZONSKOG ČIŠĆENJA
LDSL AD 2.7 SEASONAL AVAILABILITY - CLEARING

Nil

**LDSL AD 2.8 PODACI O STAJANKAMA, STAZAMA ZA VOŽNJU I
MJESTIMA PROVJERE**
LDSL AD 2.8 APRONS, TAXIWAYS AND CHECK LOCATIONS DATA

1	<i>Površina stajanke i nosivost / Apron surface and strength</i>	Površina/Surface: Voda/Water Nosivost/Strength: Nil
2	<i>Oznaka, širina, vrsta površine i nosivost staze za vožnju / Taxiway designation, width, surface and strength</i>	Širina/Width: Nil Površina/Surface: Voda/Water Nosivost/ Strength: Nil
3	<i>Položaj ACL-a i nadmorska visina / ACL location and elevation</i>	Nil
4	<i>VOR kontrolne točke /VOR checkpoints</i> <i>INS kontrolne točke / INS checkpoints</i>	Nil
5	<i>Primjedbe / Remarks</i>	Nil

**LDSL AD 2.9 SUSTAV VOĐENJA I KONTROLE KRETANJA I
OZNAKE**
**LDSL AD 2.9 SURFACE MOVEMENT GUIDANCE AND
CONTROL SYSTEM AND MARKINGS**

Nil

LDSL AD 2.10 AERODROMSKE PREPREKE
LDSL AD 2.10 AERODROME OBSTACLES

<i>U području 2/In Area 2</i>					
<i>OBST ID/Oznaka OBST ID/Designation</i>	<i>Tip OBST/ OBST type</i>	<i>Pozicija OBST/ OBST position</i>	<i>ELEV/HGT</i>	<i>Oznake/ Tip, boja Markings/ Type, colour</i>	<i>Primjedbe/ Remarks</i>
Nil	Građevina/ Building	425734.2N 0164215.6E	73ft/Nil	Nil	28/APCH 10/TKOF

<i>U području 3/In Area 3</i>					
<i>OBST ID/Oznaka OBST ID/Designation</i>	<i>Tip OBST/ OBST type</i>	<i>Pozicija OBST/ OBST position</i>	<i>ELEV/HGT</i>	<i>Oznake/ Tip, boja Markings/ Type, colour</i>	<i>Primjedbe/ Remarks</i>
Nil	Nil	Nil	Nil	Nil	Nil

LDSL AD 2.11 RASPOLOŽIVE METEOROLOŠKE INFORMACIJE

LDSL AD 2.11 METEOROLOGICAL INFORMATION PROVIDED

1	<i>Pridružen MET ured / Associated MET Office</i>	Nil
2	<i>Radno vrijeme MET ured izvan radnog vremena / Hours of service MET Office outside hours</i>	Nil
3	<i>Ured nadležan za pripremu TAF-a Razdoblja valjanosti / Office responsible for TAF preparation Periods of validity</i>	Nil
4	<i>Vrsta prognoze za slijetanje Interval izdavanja / Type of landing forecast Interval of issuance</i>	Nil
5	<i>Mogućnost informiranja/konzultacije / Briefing/consultation provided</i>	https://met.crocontrol.hr Osobne konzultacije telefonom, vidi/ Personal briefing by telephone, see: AIP LDSP AD 2.11
6	<i>Dokumentacija u svezi leta Korišteni jezik(ci) / Flight documentation Language(s) used</i>	Nil
7	<i>Karte i ostali podaci raspoloživi za informiranje ili konzultacije / Charts and other information available for briefing or consultation</i>	Nil
8	<i>Dodatni raspoloživi uređaji za pružanje informacija / Supplementary equipment available for providing information</i>	Nil
9	<i>ATS jedinice opskrbljene informacijama / ATS unit provided with information</i>	Nil
10	<i>Dodatne informacije (ograničenja u pružanju usluge, itd.) / Additional information (limitation of service, etc.)</i>	Nil

**LDSL AD 2.12 FIZIČKE KARAKTERISTIKE POVRŠINE ZA
SLIJETANJE I UZLIJETANJE -PLOVNI KANAL**
LDSL AD 2.12 WATERWAY PHYSICAL CHARACTERISTICS

<i>Oznake RWY NR</i>	<i>TRUE BRG</i>	<i>Dimenzije RWY-a (M)</i>	<i>Nosivost (PCN) i površina RWY-a i SWY-a</i>	<i>Koordinate THR Koordinate kraja RWY-a Geoidna undulacija THR-a</i>	<i>Nadmorska visina THR-a, najviša nadmorska visina TDZ-a kod RWY-a za precizan prilaz</i>
<i>Designations RWY NR</i>	<i>TRUE BRG</i>	<i>Dimensions of RWY (M)</i>	<i>Strength (PCN) and surface of RWY and SWY</i>	<i>THR coordinates RWY end coordinates THR geoid undulation</i>	<i>THR elevation and highest elevation of TDZ of precision APP RWY</i>
1	2	3	4	5	6
10	105.50°	500x150	Nil Voda/Water	425749.00N 0164121.20E Nil Nil	0 FT
28	285.51°	500x150	Nil Voda/Water	425744.67N 0164142.46E Nil Nil	0 FT
<i>Nagib RWY- SWY-a</i>	<i>Dimenzije SWY-a (M)</i>	<i>Dimenzije CWY-a (M)</i>	<i>Waterway strip dimenzije/ dimensions (M)</i>	<i>OFZ</i>	<i>Primjedbe</i>
<i>Slope of RWY-SWY</i>	<i>SWY dimensions (M)</i>	<i>CWY dimensions (M)</i>		<i>OFZ</i>	<i>Remarks</i>
7	8	9	10	11	12
Nil	Nil	Nil	Nil	Nil	Nil
Nil	Nil	Nil	Nil	Nil	Nil

LDSL AD 2.13 OBJAVLJENE UDALJENOSTI
LDSL AD 2.13 DECLARED DISTANCES

<i>Oznaka RWY-a</i>	<i>TORA</i> <i>(M)</i>	<i>TODA</i> <i>(M)</i>	<i>ASDA</i> <i>(M)</i>	<i>LDA</i> <i>(M)</i>	<i>Primjedbe</i>
<i>RWY</i> <i>Designator</i>	<i>TORA</i> <i>(M)</i>	<i>TODA</i> <i>(M)</i>	<i>ASDA</i> <i>(M)</i>	<i>LDA</i> <i>(M)</i>	<i>Remarks</i>
<i>1</i>	<i>2</i>	<i>3</i>	<i>4</i>	<i>5</i>	<i>6</i>
10	500	500	500	500	Voda/Water
28	500	500	500	500	Voda/Water

LDSL AD 2.14 PRILAZNA SVJETLA I OSVJETLJENJE UZLETNO-
SLETNE STAZE
LDSL AD 2.14 APPROACH AND RUNWAY LIGHTING

Nil

LDSL AD 2.15 OSTALA OSVJETLJENJA, SEKUNDARNI IZVOR
ELEKTRIČNE ENERGIJE
LDSL AD 2.15 OTHER LIGHTING, SECONDARY POWER SUPPLY

Nil

LDSL AD 2.16 PROSTOR ZA SLIJETANJE HELIKOPTERA
LDSL AD 2.16 HELICOPTER LANDING AREA

Nil

LDSL AD 2.17 ZRAČNI PROSTOR U NADLEŽNOSTI ATS-A
LDSL AD 2.17 ATS AIRSPACE

1	<i>Oznake i bočne granice / Designation and lateral limits</i>	ATZ LDSL Krug R= 2.5 NM s centrom u ARP-u / A circle R=2.5 NM centered at ARP
2	<i>Vertikalne granice / Vertical limits</i>	<u>1000 ft AGL</u> GND
3	<i>Klasifikacija zračnog prostora / Airspace classification</i>	G
4	<i>Pozivni znak ATS jedinice Jezik(ci) / ATS unit call sign Language(s)</i>	Nil
5	<i>Prijelazna apsolutna visina / Transition altitude</i>	10 000 FT MSL
6	<i>Primjedbe / Remarks</i>	Vidi/See LDSL AD 2.20

LDSL AD 2.18 KOMUNIKACIJSKE SLUŽBE ATS-A
LDSL AD 2.18 ATS COMMUNICATION FACILITIES

<i>Oznaka službe</i>	<i>Pozivni znak</i>	<i>Frekvencija</i>	<i>Sati rada</i>	<i>Primjedbe</i>
<i>Service designation</i>	<i>Call sign</i>	<i>Frequency</i>	<i>Hours of operation</i>	<i>Remarks</i>
1	2	3	4	5
APP	SPLIT RADAR	120.875 MHZ	H24	Primarna/Primary FREQ
		128.675 MHZ	H24	

**LDSL AD 2.19 RADIONAVIGACIJSKI UREĐAJI I UREĐAJI ZA
SLIJETANJE
LDSL AD 2.19 RADIONAVIGATION AND LANDING AIDS**

Nil

**LDSL AD 2.20 LOKALNI AERODROMSKI PROPISI
LDSL AD 2.20 LOCAL AERODROME REGULATIONS**

Prije uzlijetanja ili slijetanja pilot mora kontaktirati Lučku kapetaniju Vela Luka na VHF 10 ili 16 kanalu.

Osobe ili plovila koja ulaze na operativne površine moraju se pridržavati upute odgovorne osobe.

Ulaz na ponton za privez hidraviona je pod nadzorom djelatnika operatora aerodroma na vodi.

Pristajanje i parkiranje zrakoplova na pristanišni ponton obavlja pilot.

Pomoćno osoblje operatora aerodroma, upoznato sa operativnim i sigurnosnim procedurama vezanim uz prihvat i privez hidroaviona, pomaže pilotu pri pristajanju i privezu na platformu.

Pristanišna platforma koristi se isključivo za privez hidroaviona i pomoćnih operativnih plovila aerodroma na vodi KORČULA/Vela Luka.

Pilot zrakoplova koji namjerava obavljati let u kontroliranom zračnom prostoru, prije polijetanja mora se javiti nadležnoj kontroli zračnog prometa SPLIT APP na FREQ 120.875 MHz odnosno 128.675 MHz, ili na broj telefona +385 21 205458.

Prior to landing and take-off pilot shall contact KORČULA/Vela Luka Harbor master on marine VHF 10 or 16 channel.

Personnel and vessels entering LDSL operational surfaces shall follow instruction of LDSL personnel.

Entrance to the dock is under supervision of aerodrome personnel.

Parking/docking procedure is at pilot's discretion; aerodrome personnel is trained in operational and safety procedures regarding of docking and mooring and will help with tie down during docking of seaplane.

Dock is used for seaplanes and LDSL operational vessels only.

Prior to flight in controlled airspace, pilot shall contact SPLIT APP on FREQ 120.875 MHz or 128.675 MHz; or by phone +385 21 205458 before take off.

LDSL AD 2.21 POSTUPCI ZA SMANJENJE BUKE LDSL AD 2.21 NOISE ABATEMENT PROCEDURES

Nil

LDSL AD 2.22 POSTUPCI TIJEKOM LETA LDSL AD 2.22 FLIGHT PROCEDURES

Zrakoplovi koji prilaze na i odlaze s aerodroma na vodi KORČULA/Vela Luka primarno uspostavljaju radio-komunikaciju na Split APP/RADAR FREQ 120.875 MHz. Ako pilot nije u mogućnosti uspostaviti kontakt sa Split APP/RADAR FREQ 120.875 MHz potrebno je kontaktirati Split APP/RADAR FREQ 128.675 MHz.

DOLET/ODLET

Smjer N-NW: dolet/odlet se vrši iz/u pravcu VFR točke V2 i D3 na visini 1000 ft AGL.

Smjer E: dolet/odlet se vrši iz/u pravcu grada Korčule na visini 1000 ft AGL.

ŠKOLSKI KRUG

Školski krug je desni za stazu 28, a lijevi za stazu 10 na visini od 1000 ft AGL.

Aircraft arriving/departing to/from water aerodrome KORCULA/Vela Luka shall contact Split APP/RADAR on FREQ 120.875 MHz. If the pilot is unable to contact Split APP/RADAR on FREQ 120.875 MHz, he shall contact Split APP/RADAR on FREQ 128.675MHz.

ARRIVAL/ DEPARTURE

N-NW ARRIVAL/DEPARTURE shall be made at altitude 1000 ft AGL to/from significant VFR points V2 or D3.

E ARRIVAL/DEPARTURE shall be made at altitude 1000 ft AGL to/from Korčula City.

TRAFFIC CIRCUIT

Traffic pattern is right-hand for RWY28; left-hand for RWY10 at altitude 1000 ft AGL.

LDSL AD 2.23 DODATNE INFORMACIJE LDSL AD 2.23 ADDITIONAL INFORMATION

Nil

LDSL AD 2.24 POPRATNE KARTE AERODROMA LDSL AD 2.21 CHARTS RELATED TO AN AERODROME

<i>Ime / Name</i>	<i>Stranica / Page</i>
Aerodrome Chart	LDSL AD 2-ADC
Visual Approach Chart	LDSL AD 2-VAC